



DIRECTIONS 2261:

- STEP #1** **Remove shocks and factory sway bar if so equipped.**
- STEP #2** **Remove nuts which secure shock brackets to axle.**
- STEP #3** **Place bar over axle with arms forward and install the midsection bushings and brackets on the bar. Be sure to grease the mid bushings.**
- STEP #4** **Bolt the assembly to the shock brackets using the factory nuts and u-bolts.**
Note: This is different and improved over stock mounting location.
- STEP #6** **Install the end links to the bar.**
- STEP #7** **Reinstall the shocks**
- STEP #8** **ROAD TEST YOUR CAR TO FAMILIARIZE YOURSELF WITH ITS NEW HANDLING. AS WE CANNOT SUPERVISE YOUR INSTALLATION OR YOUR DRIVING, WE CANNOT BE HELD RESPONSIBLE FOR MORE THAN THE COST OF THE KIT. FOR BEST BALANCE AND CONTROL, THIS BAR SHOULD BE USED IN CONJUNCTION WITH OUR REAR/FRONT KIT.**

HARDWARE:

- 2 – 70W bracket**
- 2 – 614W bushing**