



Holley Fuel Rail Brackets

**Use when installing tall performance injectors with
OE style LS intakes**

P/N 534-246

Follow instructions supplied with fuel rails. If your engine RPO number is not listed below, these brackets are not required for your application.

Install the appropriate brackets onto the Holley rails using the supplied M5 X 14 socket head cap screws and M5 lock washers.

When using EV1/Bosch style performance injectors:	
LS engine RPO CODE	Fuel rail bracket pack
L92, L94, L96, L9H, LY6	Group A-P
L20, LH6, LH8, LMG, LY2, LY5, LZ1	Group B-P
L33, L59, LQ4	Group C-P

IMPORTANT: Open only the bracket pack for your application, as differences are minor and they can get confused easily.

Your engine RPO CODE can be found in the glove box. Vehicle model/year listings are available at [www.wikipedia.org/wiki/LS based GM small-block engine](http://www.wikipedia.org/wiki/LS_based_GM_small-block_engine)

199R11604
Date: 7-23-18